

HYTORC®

Since 1968

HYTORC HY-.5XLT PRESSURE/TORQUE CONVERSION CHART

PRESSURE IN PSI	PRESSURE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	55	8	75	104
1600	59	8	80	110
1800	67	9	91	124
2000	75	10	102	138
2200	83	11	113	152
2400	92	13	125	166
2600	100	14	136	179
2800	109	15	148	193
3000	117	16	159	207
3200	125	17	169	221
3400	133	18	180	235
3600	140	19	190	248
3800	148	20	201	262
4000	156	22	211	276
4200	164	23	222	290
4400	172	24	233	304
4600	181	25	245	317
4800	189	26	256	331
5000	197	27	267	345
5200	206	28	279	359
5400	215	30	291	373
5600	223	31	302	386
5800	232	32	314	400
6000	241	33	327	414
6200	249	34	338	428
6400	257	36	348	442
6600	266	37	361	455
6800	274	38	371	469
7000	282	39	382	483
7200	289	40	392	497
7400	296	41	401	511
7600	304	42	412	524
7800	311	43	422	538
8000	318	44	431	552
8200	326	45	442	566
8400	334	46	453	580
8600	342	47	464	593
8800	350	48	474	607
9000	358	50	485	621
9200	366	51	496	635
9400	374	52	507	649
9600	381	53	516	662
9800	389	54	527	676
10000	397	55	538	690

This chart supercedes all prior version regarding this tool 03/31/2008

MAIN OFFICE

12420 TEXACO RD
HOUSTON, TX 77013
713-453-6677

SOUTH TEXAS OFFICE

4802 BALDWIN BLVD
CORPUS CHRISTI, TX 78408
361-888-5080

WEST TEXAS OFFICE

3508 S. COUNTY RD 1290
ODESSA, TX 78765
432-561-8481

EAST TEXAS OFFICE

2484 W. CARDINAL AVE #4
BEAUMONT, TX 77705
409-840-9699